STYLEXModel: Adorn with Steel top

*Refer to P.2 for model variations

Disassembly and Recycling Document

Disassembly Time: 5min / No Special Training Required

Tools Required

safety glasses 1/8" allen wrench Small Screw Driver





Breakdown Steps

1. Flip the table upside down (figure A1).



2. Use an 1/8" allen key to remove the socket button head cap screws holding the frame to the top (figure B1).



3. Using a small screw driver remove the screws holding the glides to the frame (figure C1).



4. Remove glide (figure D1).



- Top

 Material: Steel, wood, glass, solid surface, ceasar stone



- Material: aluminum, steel

- Socket cap screw 10-24 X.5"

- Material: Steel

- Glides

- Material: plastic

- Screws

- Material: Steel

- Frame

- Material: Steel

